


# THERMOSTAT

## COMPONENTS



## REMOVAL

### HINT:

Removal of the thermostat would have an adverse effect, causing a lowering of cooling efficiency. Do not remove the thermostat, even if the engine tends to overheat.


#### 1. DRAIN ENGINE COOLANT (See page [CO-3](#))

#### 2. SEPARATE WATER INLET HOUSING

- Remove the 3 nuts, and separate the water inlet from the water inlet housing.

#### 3. REMOVE THERMOSTAT

- Remove the thermostat.
- Remove the gasket from the thermostat.





## INSPECTION

#### 1. INSPECT WATER INLET WITH THERMOSTAT

### HINT:

The valve opening temperature is inscribed on the thermostat.




- Immerse the thermostat in water, then gradually heat the water.

- Check the valve opening temperature of the thermostat.

### Valve opening temperature:

**80 to 84°C (176 to 183°F)**

If the valve opening temperature is not as specified, replace the thermostat.



- Check the valve lift.


### Valve lift:

**8.0 mm (0.31 in.) or more at 95°C (203°F)**

If the valve lift is not as specified, replace the thermostat.

- Check that the valve is fully closed when the thermostat is at low temperature (below 40°C (104°F)).

If not fully closed, replace the thermostat.



## INSTALLATION

### 1. INSTALL THERMOSTAT

- Install a new gasket to the thermostat.
- Insert the thermostat into the water inlet housing with the jiggle valve facing straight upward.

HINT:

The jiggle valve may be set within 30° of either side of the prescribed position.

### 2. INSTALL WATER INLET HOUSING

- Install the water inlet with the 3 nuts.

**Torque: 19 N\*m (195 kgf\*cm, 14 ft.\*lbf)**

### 3. FILL UP ENGINE COOLANT (See page [CO-3](#))