


4WD (w/o 2-4 SELECT SW)

- * 1: 5VZ-FE
- * 2: 3RZ-FE
- * 3: 5VZ-FE A/T
- * 4: 3RZ-FE A/T
- * 5: W/ REAR DIFF. LOCK
- * 6: W/O ADD
- * 7: W/ ADD



SERVICE HINTS

P1 PARK/NEUTRAL POSITION SW

4-7 :Closed with A/T shift position at **P** position

D5 DETECTION SW (TRANSFER NEUTRAL POSITION)

1-2 :Closed with transfer position at **NEUTRAL** position

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A10	26 (5VZ-FE),28 (3RZ-FE)	D5	26 (5VZ-FE),28 (3RZ-FE)	J7 A	31
A17	30	D29	30	J8 B	31
A18	30	E5 A	31	J9	31
C10 A	30	E8 D	31	P1	27 (5VZ-FE),29 (3RZ-FE)
C11 B	30	E9 A	31	V4	27 (5VZ-FE),29 (3RZ-FE)
C19 D	30	E11 C	31	V5	27 (5VZ-FE),29 (3RZ-FE)
D3	26 (5VZ-FE),28 (3RZ-FE)	J1 A	27 (5VZ-FE),29 (3RZ-FE)		
D4	26 (5VZ-FE),28 (3RZ-FE)	J2 B	27 (5VZ-FE),29 (3RZ-FE)		

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	22	Cowl Wire and Driver Side J/B (Lower Finish Panel)
1F		
3D	24	Cowl Wire and Center J/B (Near the Steering Column Tube)
3E		

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ED1	36 (5VZ-FE)	Engine Wire and Front Differential Wire (Near the Front Differential)
	38 (3RZ-FE)	Engine Wire and Front Differential Wire (Near the Starter)
IG1	40	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
II3	40	Engine Wire and Cowl Wire (On the Glove Box)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
EB	36 (5VZ-FE)	Front Left Fender
	38 (3RZ-FE)	
IF	40	Cowl Side Panel RH

○ : SPLICE POINTS


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I10	40	Cowl Wire	I19	40	Cowl Wire
I11	40	Engine Wire			

4WD (w/o 2-4 SELECT SW)


A10 GRAY




A17




A18




C10 (A) BROWN




C11 (B) BLUE




C19 (D) GRAY




D3 BLUE




D4 BLUE




D5 GRAY




D29




(3RZ-FE) E5 (A)




(3RZ-FE) E8 (D)




(5VZ-FE) E9 (A)



(5VZ-FE) E11 (C)




J1 (A), J2 (B) GRAY




(Hint : See Page 7)

J7 (A), J8 (B) BLACK




(Hint : See Page 7)

J9




(Hint : See Page 7)

P1 GRAY



V4 BROWN



V5 BLUE

