


20. INSTALL FRONT DRIVE INNER SHAFT OUTER SHAFT SNAP RING

- (a) Install a new snap ring.

**21. INSTALL OUTBOARD JOINT BOOT****HINT:**

Before installing the boots, wrap the spline of the drive shaft with vinyl tape to prevent the boots from being damaged.

- (a) Temporarily install a new outboard joint boot with 2 clamps to the drive shaft.
 (b) Pack the outboard joint assy and boot with grease in the boot kit.

Grease capacity:

260 - 270 g (9.2 - 9.5 oz.)

22. INSTALL FRONT AXLE OUTBOARD JOINT BOOT CLAMP

- (a) Mount drive shaft in a soft vise.
 (b) Secure the outboard joint boot clamps onto the boot.
 (c) Place SST onto the outboard joint large boot clamp.
 SST 09521-24010

Clearance: 0.8 mm (0.031 in.) or less

- (d) Tighten the SST so that the large clamp is pinched.



NOTICE:

Do not overtighten the SST.


- (e) Using SST, adjust the clearance of the large clamp.
 SST 09240-00020

Clearance: 0.8 mm (0.031 in.) or less

- (f) Employ the same manner to the outboard joint small boot clamp.

**23. INSTALL INBOARD JOINT BOOT**

- (a) Install a new inboard joint boot to the outboard joint shaft.

**24. INSTALL FRONT DRIVE INBOARD JOINT ASSY LH**


- Place the beveled side of the tripod axial spline toward the outboard joint.
- Align the matchmarks placed before removal.
- Using a brass bar and hammer, tap in the tripod to the drive shaft.

NOTICE:**Do not tap the roller.**


- Pack the inboard joint assy and boot with grease in the boot kit.

Grease capacity:**231 - 241 g (8.1 - 8.5 oz.)**

- Using a snap ring expander, install a new snap ring.

**25. INSTALL FRONT AXLE INBOARD JOINT BOOT CLAMP**

- Bend the band and lock a new inboard joint large boot clamp with a screwdriver.
- Using the same manner to the inboard joint small boot clamp.

**26. INSPECT FRONT DRIVE SHAFT ASSY LH**

- Check to see that there is no remarkable play in the outboard joint.
- Check to see that the inboard joint slides smoothly in the thrust direction.
- Check to see that there is no remarkable play in the radial direction of the inboard joint.
- Check the boots for damage.

NOTICE:**Move the drive shaft assy keeping it level.****27. INSTALL FRONT DRIVE SHAFT ASSY LH**


- Coat the spline of the inboard joint shaft assy with ATF.
- Align the shaft splines and install the drive shaft assy with brass bar and hammer.


NOTICE:

- Set the snap ring with opening side facing downward.
- Be careful not to damage the oil seal.

HINT:

Whether the inboard joint shaft is in contact with the pinion shaft or not can be known from the sound or feeling when driving it.



**28. INSTALL SPEED SENSOR FRONT LH**


- (a) Install the speed sensor wireharness to the steering knuckle with a bolt.

Torque: 13 N·m (133 kgf·cm, 10 ft·lbf)

- (b) Connect the 2 clips.


- (c) Using a hexagon wrench, install the speed sensor with the bolt.

Torque: 8.3 N·m (85 kgf·cm, 73 in·lbf)

**29. INSTALL FRONT SUSPENSION ARM SUB- ASSY LOWER NO.1 LH**

- (a) Install the lower ball joint to the lower suspension arm with the bolt and nut.

Torque: 225 N·m (2,294 kgf·cm, 166 ft·lbf)

**30. INSTALL TIE ROD END SUB-ASSY LH**


- (a) Install the tie rod end to the steering knuckle with the nut.

Torque: 91 N·m (928 kgf·cm, 67 ft·lbf)

- (b) Install a new cotter pin.

NOTICE:

If the holes for the cotter pin are not aligned, tighten the nut further to 60°.

**31. INSTALL FRONT AXLE HUB LH NUT**

- (a) Install the hub nut.

Torque: 294 N·m (3,000 kgf·cm, 217 ft·lbf)

- (b) Install a new cotter pin and adjusting cap.

- 32. FILL UP DIFFERENTIAL OIL (See page 29-3)
- 33. INSPECT DIFFERENTIAL OIL (See page 29-3)
- 34. INSTALL FRONT WHEEL
Torque: 112 N·m (1,142 kgf·cm, 83 ft·lbf)
- 35. CHECK ABS SPEED SENSOR SIGNAL (See page 05-803)