



Technical Service BULLETIN

October 17, 2003

Title:


REAR WIPER ARM PERFORMANCE

Models:

'03 4Runner

BODY
B0019-03

Introduction The rear wiper arm hinge has been strengthened to improve performance on 2003 model year 4Runner vehicles.



**Applicable
Vehicles**

- **2003** model year **4Runner** vehicles produced **BEFORE** the Production Change Effective VINs shown below.

**Production
Change
Information**

MODEL	PLANT	PRODUCTION CHANGE EFFECTIVE VIN	
		6 Cylinder	8 Cylinder
4Runner	Tahara	JTEZU17R230016920	JTEZT17R930013855
		JTEBU14R930019898	JTEBT14R130027514
	Hino	JTEZU14R938009226	JTEZT14R438002915
		JTEBU14RX38010936	JTEBT14R738008368

**Parts
Information**

PREVIOUS PART NUMBER	CURRENT PART NUMBER	PART NAME	QTY
85241-35030	85241-35031	Rear Wiper Arm	1

**Warranty
Information**

OP CODE	DESCRIPTION	TIME	OFP	T1	T2
850061	R & R Rear Wiper Arm	0.3	85241-35030	75	12

Applicable Warranty*:

This repair is covered under the Toyota Comprehensive Warranty. This warranty is in effect for 36 months or 36,000 miles, whichever occurs first, from the vehicle's in-service date.


* Warranty application is limited to correction of a problem based upon a customer's specific complaint.



Repair Procedure

For more information, refer to the Technical Information System (TIS) 2003 4Runner Repair Manual: Wiper & Washer, Rear Wiper Motor Assembly.

1. Remove the rear wiper arm head cap by releasing the four claws.
2. Remove the retainer nut, then remove the rear wiper arm.




3. Install new rear wiper arm.
 - A. Clean the rear wiper pivot serration with a wire brush.
 - B. Ensure the rear wiper motor is in the automatic stop position.

HINT:

To ensure that the rear wiper is in the automatic stop position:

- a) Turn the rear wiper motor switch to the ON position.
- b) Turn the wiper motor switch to the OFF position.



**Repair
Procedure**
(Continued)

- C. Hold the slider in position “A” and install the arm and blade assembly temporarily with the retainer nut finger tight.
- D. Move the slider into position “B” and tighten the nut to complete wiper arm installation.

Torque: 5.5 Nm (56 kgf•cm, 49 in.•lbf)

HINT:

Hold down on the wiper arm at the hinge point with firm pressure to facilitate retainer nut installation.

- E. Move the rear wiper arm assembly back to position “A.”
- F. Check for proper operation of the rear wiper using caution not to scratch the glass.

NOTE:

To prevent scratching of the glass surface, use running water or windshield washer fluid to lubricate the surface of the rear glass when operating the rear wiper.

