

DILL TPMS APPLICATIONS CHART ©

OE	Model	Model Year	Torque In-Lbs	OE Supplier	Dill Sensor #	Dill Kit #	Kit Color	OE Sensor Part #
Acura	CSX	08-09	35	TRW	1212	2040K	Lt. Blue	42753-SNA-A83
	MDX	04-06	35	TRW	1057	2000K	Yellow	06421-S3V-A04
	MDX	07-11	35	Pacific	1209	1100K	Purple	42753-STK-A04
	RDX	07-11	35	Pacific	1209	1100K	Purple	42753-STK-A04
	RL	05-08	35	TRW	1057	2000K	Yellow	06421-S3V-A04
	RL	09-10	35	TRW	1211	2040K	Lt. Blue	42753-SHJ-A53
	RL	09-10	35	TRW	1057	2000K	Yellow	Replaces Fixed Angle Sensor
	TL	06-08	35	TRW	1057	2000K	Yellow	06421-S3V-A04
	TL(Hi-Line)	09-11	35	TRW	1214	2040K	Lt. Blue	42753-TK4-A01
	TSX	07-08	35	Pacific	1209	1100K	Purple	42753-STK-A04
	TSX	09-10	35	Pacific	1204	1100K	Purple	42753-TL2-A52
	ZDX(Hi-Line)	10	35	TRW	1214	2040K	Lt. Blue	42753-TK4-A01
Audi	Allroad(315 Mhz)	01-05	35	Beru	9004	1090K	Gray	4D0 907 275A
	A6 Allroad(433 Mhz)	01-06	35	Beru	9001	1090K	Gray	4D0 907 275C
	A6 Allroad(433 Mhz)	07-09	35	Beru	9007	1090K	Gray	4F0 907 275B
	A6 Allroad(433 Mhz)	10	35	Beru	9011	1090K	Gray	4F0 907 275D
	A3(315 Mhz)	06-11	71	Siemens	1053	1030K	Orange	1K0907253D
	A4(433 Mhz)	02-08	35	Beru	9007	1090K	Gray	4F0 907 275B
	A4 (315 Mhz)	09-11	71	Continental	1053	1030K	Orange	1K0907253D
	A5(315 Mhz)	08-11	71	Siemens	1053	1030K	Orange	1K0907253D
	A6(315 Mhz)	02-04	35	Beru	9004	1090K	Gray	4D0 907 275A
	A6(433 Mhz)	05-09	35	Beru	9007	1090K	Gray	4F0 907 275B
	A6(433 Mhz)	10-11	35	Beru	9011	1090K	Gray	4F0 907 275D
	A8(315 Mhz)	01-07	35	Beru	9004	1090K	Gray	4D0 907 275A
	A8(433 Mhz)	00-11	35	Beru	9001	1090K	Gray	4D0 907 275C
	Q5(315 Mhz)	09-11	71	Continental	1053	1030K	Orange	1K0907253D
	Q7(433 Mhz)	05-09	35	Beru	9007	1090K	Gray	4F0 907 275B
	Q7(433 Mhz)	10-11	35	Beru	9011	1090K	Gray	4F0 907 275D
	R8(433 Mhz)	08-09	35	Beru	9007	1090K	Gray	4F0 907 275B
	R8(433 Mhz)	10-11	35	Beru	9011	1090K	Gray	4F0 907 275D
	RS4(433 Mhz)	07-09	35	Beru	9007	1090K	Gray	4F0 907 275B
	RS6(315 Mhz)	01-05	35	Beru	9004	1090K	Gray	4D0 907 275A
	RS6(433 Mhz)	01-05	35	Beru	9001	1090K	Gray	4D0 907 275C
	S4(433 Mhz)	02-08	35	Beru	9007	1090K	Gray	4F0 907 275B
	S4(315 Mhz)	10-11	71	Siemens	1053	1030K	Orange	1K0907253D
	S5(315 Mhz)	08-11	71	Siemens	1053	1030K	Orange	1K0907253D
	S6(433 Mhz)	04-09	35	Beru	9007	1090K	Gray	4F0 907 275B
	S6(433 Mhz)	10-11	35	Beru	9011	1090K	Gray	4F0 907 275D
	S8(315 Mhz)	01-07	35	Beru	9004	1090K	Gray	4D0 907 275A
	S8(433 Mhz)	00-09	35	Beru	9001	1090K	Gray	4D0 907 275C
	TT(315 Mhz)	08-11	71	Siemens	1053	1030K	Orange	1K0907253D
Bentley	Continental GT	03-05	35	Beru	9001	1090K	Gray	4D0 907 275C
	Continental GT	06-10	35	Beru	9007	1090K	Gray	4F0 907 275B
BMW	1 Series(433 Mhz)	07-11	35	Beru	1027	1090K	Gray	36 23 6 781 847
	3 Series(315 Mhz)	00-02	35	Beru	9004	1090K	Gray	36 11 8 378 681
	3 Series(433 Mhz)	01-06	35	Beru	9002	1090K	Gray	36 11 8 378 682
	3 Series(433 Mhz)	07-10	35	Beru	1027	1090K	Gray	36 23 6 781 847
	3 Series(433 Mhz) (September 2009)	10-11	35	Beru	9012	1090K	Gray	36 10 6 790 054

DILL TPMS APPLICATIONS CHART ©

OE	Model	Model Year	Torque In-Lbs	OE Supplier	Dill Sensor #	Dill Kit #	Kit Color	OE Sensor Part #
BMW	5 Series(315 Mhz)	00-02	35	Beru	9004	1090K	Gray	36 11 8 378 681
	5 Series(433 Mhz)	02-05	35	Beru	9002	1090K	Gray	36 11 8 378 682
	5 Series(433 Mhz)	06-11	35	Beru	1027	1090K	Gray	36 23 6 781 847
	6 Series(433 Mhz)	06-10	35	Beru	1027	1090K	Gray	36 23 6 781 847
	7 Series(315 Mhz)	00-01	35	Beru	9004	1090K	Gray	36 11 8 378 681
	7 Series(433 Mhz)	02-05	35	Beru	9002	1090K	Gray	36 11 8 378 682
	7 Series(433 Mhz)	06-11	35	Beru	1027	1090K	Gray	36 23 6 781 847
	M Series(433 Mhz)	03-10	35	Beru	1027	1090K	Gray	36 23 6 781 847
	M Series(433 Mhz) (September 2009)	10-11	35	Beru	9012	1090K	Gray	36 10 6 790 054
	X3(433 Mhz)	06-10	35	Beru	1027	1090K	Gray	36 23 6 781 847
	X5(433 Mhz)	01-04	35	Beru	9003	1090K	Gray	36 14 6 752 128
	X5(433 Mhz)	05-11	35	Beru	1027	1090K	Gray	36 23 6 781 847
	X6(433 Mhz)	08-11	35	Beru	1027	1090K	Gray	36 23 6 781 847
	Z Series(433 Mhz)	06-11	35	Beru	1027	1090K	Gray	36 23 6 781 847
	Alpina(433 Mhz)	04-08	35	Beru	9002	1090K	Gray	36 11 8 378 682
Bugatti	Veyron	05-06	NA	Beru	NA	1090K	Gray	NA
Buick	Allure	07-08	80	Siemens	1047	1050K	White	15921013
	Allure	09-10	---	Schrader	9153	VS950	NA	12768826
	Enclave	08	80	Siemens	1047	1050K	White	15921013
	Enclave	09-11	---	Schrader	9153	VS950	NA	25920615
	LaCrosse	07-08	80	Siemens	1047	1050K	White	15921013
	LaCrosse	09-11	---	Schrader	9153	VS950	NA	12768826
	Lesabre	07	---	Schrader	9153	VS950	NA	25799331
	Lucerne	07-11	---	Schrader	9153	VS950	NA	25920615
	Ranier(315 Mhz)	06-07	62	Schrader	9116	1070K	Blue	25774006
	Ranier(315 Mhz)	07	---	Schrader	9153	VS950	NA	25799331
Cadillac	Regal	11	---	Schrader	9153	VS950	NA	20922900
	CTS	04-07	62	Schrader	9116	1070K	Blue	25774006
	CTS	08-11	---	Schrader	9153	VS950	NA	25920615
	CTS-V	09-11	---	Schrader	1047	1050K	White	15268606
	Deville	01-05	62	Schrader	9117	1080K	Green	25773946
	DTS	06	80	Schrader	**	1047 or 1070K	White or Blue	15268606
	DTS	07-11	---	Schrader	9153	VS950	NA	25920615
	Escalade-ESV-EXT	04	62	Schrader	9115	1070K	Blue	15136883
	Escalade-ESV-EXT	05-06	62	Schrader	9107	1070K	Blue	15114379
	Escalade-ESV-EXT	07	62	TRW	NA	2020K	Pink	15825475
	Escalade-ESV-EXT	07	80	Siemens	1047	1050K	White	TRW Sensor Replacement
	Escalade-ESV-EXT	07-11	---	Schrader	9153	VS950	NA	25920615
	Seville	01-04	62	Schrader	9117	1080K	Green	25773946
	SRX	04-06	62	Schrader	9116	1070K	Blue	25774006
	SRX	07-11	---	Schrader	9153	VS950	NA	12768826
	STS	05-08	62	Schrader	9076	1070K	Blue	25758220
	STS	09	80	Schrader	**	1047 or 1070K	White or Blue	15268606
	STS	09-11	---	Schrader	9153	VS950	NA	25920615
	XLR	04-09	62	Schrader	9076	1070K	Blue	25758220

****The 1050K is to be used on the Siemens sensors and the 1070K is to be used on the Schrader sensors.**

DILL TPMS APPLICATIONS CHART ©

OE	Model	Model Year	Torque In-Lbs	OE Supplier	Dill Sensor #	Dill Kit #	Kit Color	OE Sensor Part #
Chevrolet	Avalanche	04	62	Schrader	9115	1070K	Blue	15136883
	Avalanche	05-06	62	Schrader	9107	1070K	Blue	15114379
	Avalanche	07	62	TRW	NA	2020K	Pink	15825475
	Avalanche	07	80	Siemens	1047	1050K	White	TRW Sensor Replacement
	Avalanche	07-11	---	Schrader	9153	VS950	NA	25920615
	Aveo	07-11	---	Schrader	9153	VS950	NA	25920615
	Camaro	10-11	---	Schrader	9153	VS950	NA	12768826
	Cobalt	08-10	80	Siemens	1047	1050K	White	15268606
	Cobalt	08-10	---	Schrader	9153	VS950	NA	12768826
	Colorado	07-10	62	Schrader	9131	1110K	Teal	15122618
	Corvette	97-00	62	Schrader	8006	2040K	Lt. Blue	10438853
	Corvette-C5-Z6	01-04	62	Schrader	9117	1080K	Green	25773946
	Corvette-C6	05-09	62	Schrader	9076	1070K	Blue	25758220
	Corvette	10-11	80	Schrader	1047 **	1050K or 1070K	White or Blue	15268606
	Cruze	11	---	Schrader	9153	VS950	NA	12768826
	Equinox	07-09	80	Siemens	1047	1050K	White	15921013
	Equinox	10	---	Schrader	9153	VS950	NA	12768826
	Express Series	08-09	80	Siemens	1047	1050K	White	15921013
	Express Series	10	---	Schrader	9153	VS950	NA	25920615
	G Series	08	80	Siemens	1047	1050K	White	15921013
	HHR	08-09	80	Schrader	1047 **	1050K or 1070K	White or Blue	15268606
	HHR	08-11	---	Schrader	9153	VS950	NA	25920615
	Impala	06-07	80	Schrader	1047 **	1050K or 1070K	White or Blue	15268606
	Impala	07-11	---	Schrader	9153	VS950	NA	25920615
	Malibu(< 10/14/07)	08	80	Siemens	1047	1050K	White	15921013
	Malibu	08-11	---	Schrader	9153	VS950	NA	12768826
	Monte Carlo	06-07	80	Schrader	1047 **	1050K or 1070K	White or Blue	15268606
	Monte Carlo	07	---	Schrader	9153	VS950	NA	25920615
	Silverado	04	62	Schrader	9115	1070K	Blue	15136883
	Silverado	05-06	62	Schrader	9107	1070K	Blue	15114379
	Silverado	07	62	TRW	NA	2020K	Pink	15825475
	Silverado	07	80	Siemens	1047	1050K	White	TRW Sensor Replacement
	Silverado	07-11	---	Schrader	9153	VS950	NA	25920615
	SSR	06-07	62	Schrader	9116	1070K	Blue	25774006
	Suburban	04	62	Schrader	9115	1070K	Blue	15136883
	Suburban	05-06	62	Schrader	9107	1070K	Blue	15114379
	Suburban	07	62	TRW	NA	2020K	Pink	15825475
	Suburban	07	80	Siemens	1047	1050K	White	TRW Sensor Replacement
	Suburban	07-10	---	Schrader	9153	VS950	NA	25920615
	Tahoe	04	62	Schrader	9115	1070K	Blue	15136883
	Tahoe	05-06	62	Schrader	9107	1070K	Blue	15114379
	Tahoe	07	62	TRW	NA	2020K	Pink	15825475
	Tahoe	07	80	Siemens	1047	1050K	White	TRW Sensor Replacement
	Tahoe	07-10	---	Schrader	9153	VS950	NA	25920615

DILL TPMS APPLICATIONS CHART ©

OE	Model	Model Year	Torque In-Lbs	OE Supplier	Dill Sensor #	Dill Kit #	Kit Color	OE Sensor Part #
Chevrolet	Trailblazer	06-09	62	Schrader	9116	1070K	Blue	25774006
	Traverse	09-11	62	Schrader	9153	VS950	NA	25920615
	Uplander	08-09	80	Schrader	1047 **	1050K or 1070K	White or Blue	15268606
	Volt	10-11	---	Schrader	9153	VS950	NA	12768826
**The 1050K is to be used on the Siemens sensors and the 1070K is to be used on the Schrader sensors.								
Chrysler	300	05-07	71	Siemens	1051	1050K	White	68111696AA
	300(433 Mhz)	08	71	Siemens	1043	1050K	White	68001698AB
	300(433 Mhz)	09-10	71	Schrader	9214	2030K	Lt Grey	56029400AC
	300(Alloy)	10	---	Schrader	9398	VS950	NA	56029398AA
	300M(433 Mhz)	02-04	35	Schrader	9028	1080K	Green	52088990AC
	Aspen	07-09	71	Schrader	1051 **	1050K or 2030K	White or Lt Grey	56029465AB
	Concorde(433 Mhz)	02-04	35	Schrader	9028	1080K	Green	52088990AC
	Crossfire(433 Mhz)	04-05	35	Schrader	9028	1080K	Green	52088990AC
	Crossfire	05	35	Schrader	1051 **	1050K or 2030K	White or Lt Grey	56053030AB
	Crossfire(433 Mhz)	06-08	35	Schrader	9028	1080K	Green	52088990AC
	Crossfire	06-08	71	Siemens	1051	1050K	White	56053030AB
	Intrepid(433 Mhz)	02-04	35	Schrader	9028	1080K	Green	52088990AC
	Pacifica(433 Mhz)	04	35	Schrader	9028	1080K	Green	52088990AC
	Pacifica	04-05	71	Siemens	1052	1050K	White	04727392AB
	Pacifica	06-08	71	Siemens	1051	1050K	White	68001696AB
	Prowler(433 Mhz)	02	35	Schrader	9028	1080K	Green	52088990AC
	PT Cruiser	08-10	71	Siemens	1051	1050K	White	68001696AB
	Sebring(433 Mhz)	08-09	71	Siemens	1043	1050K	White	68001698AB
	Sebring(315 Mhz)	07-10	71	Siemens	1051	1050K	White	68001696AB
	Town & Country(433 Mhz)	02-03	35	Schrader	9028	1080K	Green	52088990AC
	Town & Country	04-05	71	Siemens	1052	1050K	White	04727392AB
	Town & Country	06-08	71	Siemens	1051	1050K	White	56053030AB
	Town & Country (433 Mhz)	08-11	71	Siemens	1043	1050K	White	68001698AB
	Town & Country (433 Mhz)	11	71	Continental	NEW	7000K	White	68078768AA
	Voyager(433 Mhz)	02-03	35	Schrader	9028	1080K	Green	52088990AC
**The 1050K is to be used on the Siemens sensors and the 2030K is to be used on the Schrader sensors.								
Dodge	Avenger	08-10	71	Siemens	1051	1050K	White	68001696AB
	Caliber	07-10	71	Siemens	1051	1050K	White	68001696AB
	Caravan(433 Mhz)	02-03	35	Schrader	9028	1080K	Green	52088990AC
	Caravan	04-05	71	Siemens	1052	1050K	White	04727392AB
	Caravan	06-07	71	Siemens	1051	1050K	White	56053030AB
	Challenger (433 Mhz)	08	71	Siemens	1043	1050K	White	68001698AB
	Challenger (433 Mhz)	09-10	71	Schrader	9214	2030K	Lt Grey	56029400AC
	Challenger(Alloy)	10	---	Schrader	9398	VS950	NA	56029398AA
	Charger	06-07	71	Siemens	1051	1050K	White	68001696AB
	Charger(433 Mhz)	08	71	Siemens	1043	1050K	White	68001698AB

DILL TPMS APPLICATIONS CHART ©

OE	Model	Model Year	Torque In-Lbs	OE Supplier	Dill Sensor #	Dill Kit #	Kit Color	OE Sensor Part #
Dodge	Charger(433 Mhz)-SRT	09-10	71	Schrader	9214	2030K	Lt Grey	56029400AC
	Charger(Alloy)	10	---	Schrader	9398	VS950	NA	56029398AA
	Dakota(HP)	08-10	53	Schrader	9154	2030K	Lt Grey	56029319AB
	Dakota	11	---	Schrader	9308	VS950	NA	56029479AA
	Dakota	11	71	Schrader	1051	1050K	White	Sensor Replacement Only
	Durango	07-09	71	Schrader	1051 **	1050K or 2030K	White or Lt Grey	56029465AB
	Grand Caravan(433 Mhz)	02-03	35	Schrader	9028	1080K	Green	52088990AC
	Grand Caravan	04-05	71	Siemens	1052	1050K	White	04727392AB
	Grand Caravan	06-07	71	Siemens	1051	1050K	White	56053030AB
	Grand Caravan (433 Mhz)-- Thru 11/30/09	08-10	71	Siemens	1043	1050K	White	68001698AB
	Grand Caravan-- Post 12/1/09	10	71	Siemens	1043	1050K	White	68078768AA (Sensor replacement only)
	Journey(433 Mhz)	09-10	71	Siemens	1043	1050K	White	68001698AB
	Magnum	05-07	71	Siemens	1051	1050K	White	68001696AB
	Magnum(433 Mhz)	08	71	Siemens	1043	1050K	White	68001698AB
	Magnum(433 Mhz)	09	71	Schrader	9214	2030K	Lt Grey	56029400AB
	Nitro	07-11	71	Schrader	1051 **	1050K or 2030K	White or Lt Grey	56029465AB
	Nitro(Alloy)	10-11	---	Schrader	9308	VS950	NA	56029479AA
	Nitro(Alloy)	10	---	Schrader	1051	1050K	White	Sensor Replacement Only
	Ram(HP-315 Mhz) 1500/2500	08-09	53	Schrader	9154	2030K	Lt Grey	56029319AB
	Ram(433 Mhz) 1500/2500	09-10	71	Schrader	1043	1050K	White	56029359AA
	Ram(433 Mhz) 1500/2500	10-11	---	Schrader	9398	VS950	NA	56029398AA
	Sprinter	07-10	54	Siemens	1042	1098K	Reddish/ Purple	68038945AA
	Stratus	07	71	Siemens	1051	1050K	White	56053030AB
	Viper(433 Mhz)	03-10	35	Schrader	9028	1080K	Green	52088990AC
**The 1050K is to be used on the Siemens sensors and the 2030K is to be used on the Schrader sensors.								
Ferrari	458(433 Mhz)	10	---	Beru				
	550(433 Mhz)	02-09	---	Beru	9001	1090K	Gray	22 45 49
	575(433 Mhz)	02-09	---	Beru	9001	1090K	Gray	22 45 49
	575(315 Mhz)	02-05	---	Beru	9004	1090K	Gray	22 45 48
	599							
	612(433 Mhz)	02-09	---	Beru	9001	1090K	Gray	22 45 49
	California(433 Mhz)	10						24 88 87
	Enzo(433 Mhz)	03-09	---	Beru	9005	1090K	Gray	22 45 51
	FXX(433 Mhz)	03-09	---	Beru	9005	1090K	Gray	22 45 51
	Spider(433 Mhz)	02-09	---	Beru	9001	1090K	Gray	22 45 49
Ford	E Series	10-11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Edge	11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Escape	09-11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Expedition(433 Mhz)	03-04	44	Schrader	9096	1060K	Rubine Red	4L2T1A150BA
	Expedition(315 Mhz)	05-06	44	Schrader	9135	1060K	Rubine Red	5L1ZA150AB
	Expedition	11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Explorer	11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Explorer(433 Mhz)	03-05	44	Schrader	9096	1060K	Rubine Red	4L2T1A150BA

DILL TPMS APPLICATIONS CHART ©

OE	Model	Model Year	Torque In-Lbs	OE Supplier	Dill Sensor #	Dill Kit #	Kit Color	OE Sensor Part #
Ford	F 150	09-10	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Fiesta	11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Flex	11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Focus	10-11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Freestar(315 Mhz)	04-05	44	Schrader	9135	1060K	Rubine Red	5L1ZA150AB
	Fusion	10-11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Mustang	10-11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Super Duty (250/350/450) Post-June 2009	10-11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Taurus(Post-May 2010)	11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Transit	10-11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A

Banded Sensor

				Clip	Sensor	Band	Cradle	
Ford/ Lincoln/ Mazda/ Mercury	Escape-Explorer-Freestar- Mariner-Monterey- Mountaineer-Tribute-Town Car	06		1026	1048	1194	1025	6F2Z1A189A-6L2T1A150AA- 6F2A1A176AE-6F2T1A150AE
Ford/ Lincoln/ Mazda/ Mercury	B Series-Edge-Escape- Expedition-Explorer-F Series- Freestar-Focus-Fusion- Grand Marquis-Mariner-Mark LT-MKX-MKZ-Montego- Monterey-Mountaineer- Mustang-Navigator-Ranger- Sport Trac-Town Car	07		1026	1048	1194	1025	6F2Z1A189A
Ford/ Lincoln/ Mazda/ Mercury	500-B Series-Crown Victoria- Edge-Escape-Expedition- Explorer-F Series-Focus- Freestar-Fusion-Grand Marquis-Mariner-Mark LT- Milan-MKX-MKZ- Mountaineer-Mustang- Navigator-Ranger-Sable- Sport Trac-Taurus-Taurus X- Town Car-Tribute	08		1026	1048	1194	1025	6F2Z1A189A
	F Series(Super Duty)-E Series-Mark LT (High Pressure) (Pre June 2009)	07-10		1026	1048-HP	1194	1025	8C2T1A150BA- 8C2Z1A189A
Ford/ Lincoln/ Mazda/ Mercury	500-B Series-Crown Victoria- Edge-Expedition-Explorer- Flex-Focus-Freestar-Fusion- Grand Marquis-Milan-MKS- MKX-MKZ-Montego- Mountaineer-Mustang- Navigator-Ranger-Sable- Sport Trac-Taurus-Taurus X- Town Car	09		1026	1048	1194	1025	6F2Z1A189A- ZZC1-37-140 7L1Z-1A189A
Ford/ Lincoln/ Mazda/ Mercury	Crown Victoria-Edge- Expedition-Explorer-Flex- Grand Marquis-MKS-MKT- MKX-Mountaineer-Navigator- Ranger-Sport Trac-Taurus- Town Car	10		1026	1048	1194	1025	7L1Z-1A189A
Ford/Lincoln	Ranger-Town Car	11		1026	1048	1194	1025	6F2Z-1A189A

DILL TPMS APPLICATIONS CHART ©

OE	Model	Model Year	Torque In-Lbs	OE Supplier	Dill Sensor #	Dill Kit #	Kit Color	OE Sensor Part #
GMC	Acadia	07-08	80	Siemens	1047	1050K	White	15921013
	Acadia	09-11	---	Schrader	9153	VS950	NA	25920615
	Canyon	07-10	62	Schrader	9131	1110K	Teal	15122618
	Envoy	05-09	62	Schrader	9116	1070K	Blue	25774006
	Envoy	07-09	---	Schrader	9153	VS950	NA	25920615
	Savana	08-09	80	Siemens	1047	1050K	White	15921013
	Savana	10	---	Schrader	9153	VS950	NA	25920615
	Sierra(all)	04	62	Schrader	9115	1070K	Blue	15136883
	Sierra(all)	05-06	62	Schrader	9107	1070K	Blue	15114379
	Sierra(all)	07	62	TRW	NA	2020K	Pink	15825475
	Sierra(all)	07	80	Siemens	1047	1050K	White	TRW Sensor Replacement
	Sierra(all)	07-11	---	Schrader	9153	VS950	NA	25920615
	Terrain	10-11	---	Schrader	9153	VS950	NA	12768826
	Yukon(all)	04	62	Schrader	9115	1070K	Blue	15136883
	Yukon(all)	05-06	62	Schrader	9107	1070K	Blue	15114379
	Yukon(all)	07	62	TRW	NA	2020K	Pink	15825475
	Yukon(all)	07	80	Siemens	1047	1050K	White	TRW Sensor Replacement
	Yukon(all)	07-10	---	Schrader	9153	VS950	NA	25920615
Honda	Accord	08-11	35	Pacific	1208	1100K	Purple	42753-SWA-316
	Civic	08-11	35	TRW	1212	2040K	Lt Blue	42753-SNA-A83
	CR-V(Both)	07-11	35	Pacific	1208	1100K	Purple	42753-SWA-315/316
	CR-Z	11	35	TRW	1212	2040K	Lt Blue	42753-SNA-A83
	Crosstour	10		Continental	NEW	7000K		42753-TP6-A82
	Element	06-07	35	TRW	1058	2000K	Yellow	06421-SCV-A01
	Element	08	35	TRW	1210	2040K	Lt Blue	42753-SHJ-A82
	Element	08	35	TRW	1058	2000K	Yellow	Replaces Fixed Angle Sensor
	Element	09-10	35	TRW	1212	2040K	Lt Blue	42753-SNA-A83
	Fit	08	35	Pacific	1208	1100K	Purple	42753-SWA-316
	Fit	09-10	35	TRW	1212	2040K	Lt Blue	42753-SNA-A83
	Insight	10	35	TRW	1212	2040K	Lt Blue	42753-SNA-A83
	Odyssey	06-07	35	TRW	1058	2000K	Yellow	06421-SCV-A00
	Odyssey	08-10	35	TRW	1210	2040K	Lt Blue	42753-SHJ-A82
	Odyssey	08-10	35	TRW	1058	2000K	Yellow	Replaces Fixed Angle Sensor
	Odyssey	11	35	TRW	1212	2040K	Lt Blue	42753-SNA-A83
	Odyssey(Touring)	05-07	35	TRW	1057	2000K	Yellow	06421-S3V-A04
	Odyssey(Touring)	08-10	35	TRW	1211	2040K	Lt Blue	42753-SHJ-A53
	Odyssey(Touring)	08-10	35	TRW	1057	2000K	Yellow	Replaces Fixed Angle Sensor
	Odyssey(Touring)	11	35	TRW	1212	2040K	Lt Blue	42753-SNA-A83
	Pilot(Steel)-2.25"	05	35	TRW	1059	2000K	Yellow	06421-S9V-A02
	Pilot-1.75"	05-08	35	TRW	1057	2000K	Yellow	06421-S3V-A04
	Pilot	09-11	35	Pacific	1209	1100K	Purple	42753-STK-A04
	Pilot(Steel)	09-10		Pacific				42753-SZA-A12
	Ridgeline(RT)-2.25"	06-08	35	TRW	1059	2000K	Yellow	06421-S9V-A02
	Ridgeline-1.75"	06-09	35	TRW	1057	2000K	Yellow	06421-S3V-A04
	Ridgeline(Alloy)	09-11	35	TRW	1211	2040K	Lt Blue	42753-SHJ-A53
	Ridgeline(Alloy)	09-10	35	TRW	1057	2000K	Yellow	Replaces Fixed Angle Sensor
	S2000	08-09	35	Pacific	NA	1100K	Purple	42753-S2A-315
Hummer	H2	08-10	---	Schrader	9153	VS950	NA	25920615
	H3	06-10	62	Schrader	9131	1110K	Teal	15122618
	H3T	09-10	62	Schrader	9131	1110K	Teal	15122618
Hyundai	Accent(Lo-Line)	08-11	31-40	TRW	1029**	2040K	Lt Blue	52933-2F000
	Azera	07-11	31-40	Beru	1068	2000K	Yellow	52933-2G200
	Elantra	07-11	31-40	Beru	1068	2000K	Yellow	52933-2G200
	Elantra(Touring)	10-11	80	Continental	NEW	1050K	White	52933-2L500

DILL TPMS APPLICATIONS CHART ©

OE	Model	Model Year	Torque In-Lbs	OE Supplier	Dill Sensor #	Dill Kit #	Kit Color	OE Sensor Part #
Hyundai	Entourage	07-10	31-40	Beru	1028	2000K	Yellow	52933-4D200
	Equus	11	31-40	TRW	1029	2040K	Lt Blue	52933-2F000
	Genesis(Hi-line)	09-11	31-40	TRW	1029	2040K	Lt Blue	52933-2F000
	Genesis Coupe	10-11		Continental	NEW	7000K		52933-2M000
	Santa Fe (Thru July 2007)	07-08	31-40	Beru	1028	2000K	Yellow	52933-4D200
	Santa Fe (Thru Sept 2009)	08-10	31-40	Beru	1068	2000K	Yellow	52933-2G200
	Santa Fe(Oct 2009)	10	---	Beru	NEW			52933-0W100
	Sonata	07-08	31-40	TRW	1058	2000K	Yellow	52933-3E000
	Sonata(Lo-Line) --Late '08 Builds	08-10	31-40	TRW	1029**	2040K	Lt Blue	52933-2F000
	Sonata	11		Continental	NEW	7000K		52933-2M000
	Tiburon	07-08	31-40	TRW	1058	2000K	Yellow	52933-3E000
	Tucson	07-10	31-40	TRW	1058	2000K	Yellow	52933-3E000
	Tucson	10-11	31-40	TRW	1029	2040K	Lt Blue	52933-2F000
	Veracruz	06-08	31-40	Beru	1028	2000K	Yellow	52933-4D200
	Veracruz	08-11	31-40	Beru	1068	2000K	Yellow	52933-2G200
** Note: Use "TRW LoLine Fxd Dly" function on BarTec 400 or 400P to program the sensors.								
Infiniti	EX35	08	45-60	Schrader	9064	1080K	Green	40700-CD001
	EX35	09-10	66	Pacific	9204	2030K	Lt Grey	40700-JK00C
	FX35	03-08	45-60	Schrader	9064	1080K	Green	40700-CD001
	FX35	08-10	66	Pacific	9204	2030K	Lt Grey	40700-JK00C
	FX45	03-08	45-60	Schrader	9064	1080K	Green	40700-CD001
	FX50	09-10	66	Pacific	9204	2030K	Lt Grey	40700-JK00C
	G35	03-06	45-60	Schrader	9064	1080K	Green	40700-CD001
	G35	07-08	66	Pacific	9204	2030K	Lt Grey	40700-JK00C
	G37	08-10	66	Pacific	9204	2030K	Lt Grey	40700-JK00C
	M35	06-07	45-60	Schrader	9064	1080K	Green	40700-CD001
	M35	08-10	66	Schrader	9204	2030K	Lt Grey	40700-1AA0C
	M37	11						40700-1LA0A
	M45	03-07	45-60	Schrader	9064	1080K	Green	40700-CD001
	M45	08-10	66	Schrader	9204	2030K	Lt Grey	40700-1AA0C
	M56	11						40700-1LA0A
	Q45(pre-July)	03-06	45-60	Schrader	9064	1080K	Green	40700-CD001
	Q45(Post-Aug)	06	66	Schrader	9204	2030K	Lt Grey	40700-JA01B
	QX4	03	45-60	Schrader	9064	1080K	Green	40700-CD001
	QX56(Steel)	05-06	49	Schrader	9069	1130K	Burgundy	40700-CK002
	QX56(Alloy)	04-07	49	Schrader	9161	1080K	Green	40700-CK001
	QX56(Post-April)	07-10	66	Pacific	9204	2030K	Lt Grey	40700-JK00C
Isuzu	Ascender	06-08	62	Schrader	9116	1070K	Blue	25774006
	I-290	07-08	62	Schrader	9131	1110K	Teal	15122618
	I-370	07-08	62	Schrader	9131	1110K	Teal	15122618
	Rodeo(433 Mhz)	04	35	Schrader	9028	1080K	Green	52088990AC
Jaguar	S(315 Mhz)	05-09	71	Siemens	1055	1050K	White	C2Z15017
	S(433 Mhz)	05-09	71	Siemens	1046	1050K	White	C2Z15016
	XF(315 Mhz)	09-10	71	Siemens	1055	1050K	White	C2Z15017
	XF(433 Mhz)	09-10	71	Siemens	1046	1050K	White	C2Z15016
	XJ(315 Mhz)	04-10	71	Siemens	1055	1050K	White	C2Z15017
	XJ(433 Mhz)	04-10	71	Siemens	1046	1050K	White	C2Z15016
	XK(315 Mhz)	07-10	71	Siemens	1055	1050K	White	C2Z15017
	XK(433 Mhz)	07-10	71	Siemens	1046	1050K	White	C2Z15016

DILL TPMS APPLICATIONS CHART ©

OE	Model	Model Year	Torque In-Lbs	OE Supplier	Dill Sensor #	Dill Kit #	Kit Color	OE Sensor Part #
Jeep	Commander	06-07	71	Siemens	1051	1050K	White	56029465AB
	Commander (433 Mhz)	08-10	71	Schrader	1043 **	1050K or 2030K	White or Lt Grey	56029359AB
	Compass	07-10	71	Siemens	1051	1050K	White	68001696AA
	Grand Cherokee(433 Mhz)	02-04	64	Schrader	9028	1080K	Green	52088990AC
	Grand Cherokee	05-07	71	Siemens	1051	1050K	White	68001696AB
	Grand Cherokee (433 Mhz)	08-10	71	Schrader	1043 **	1050K or 2030K	White or Lt Grey	56029359AB
	Grand Cherokee	11	---	Schrader	9398	VS950	NA	56029398AA
	Liberty(433 Mhz)	04	64	Schrader	9028	1080K	Green	52088990AC
	Liberty	05-06	71	Siemens	1051	1050K	White	56029465AB
	Liberty	07-08	71	Schrader	1051 **	1050K or 2030K	White or Lt Grey	56029465AB
	Liberty(433 Mhz)	09	71	Schrader	1043 **	1050K or 2030K	White or Lt Grey	56029359AB
	Liberty	10-11	---	Schrader	9308	VS950	NA	56029479AA
	Liberty	10	---	Schrader	1051	1050K	White	68001696AA
	Patriot	07-10	71	Siemens	1051	1050K	White	68001696AA
	Wrangler(Alloy)	07-8	71	Schrader	1051 **	1050K or 2030K	White or Lt Grey	56029465AB
	Wrangler(Alloy)	09-10	71	Schrader	1043 **	1050K or 2030K	White or Lt Grey	56029359AB
	Wrangler	10-11	---	Schrader	9308	VS950	NA	56029479AA

****The 1050K is to be used on the Siemens sensors and the 2030K is to be used on the Schrader sensors.**

KIA	Amanti	07-09	31-40	TRW	1058	2000K	Yellow	52933-3E000
	Borrego(Lo-Line)	09	31-40	TRW	1029**	2040K	Lt Blue	52933-2F000
	Forte	10		Continental	NEW	7000K		52933-2M000
	Magentis	08-10	31-40	Beru	1068	2000K	Yellow	52933-2G200
	Mohave	09	31-40	TRW	1029**	2040K	Lt Blue	52933-2F000
	Optima(Hi-Line)	06-10	31-40	Beru	1068	2000K	Yellow	52933-2G200
	Rio(Lo-Line)	08-10	31-40	TRW	1029**	2040K	Lt Blue	52933-2F000
	Rio 5(Lo-Line) -- Post 7/2/07	08-10	31-40	TRW	1029**	2040K	Lt Blue	52933-2F000
	Rondo(Hi-Line)	06-09	31-40	Beru	1068	2000K	Yellow	52933-2G200
	Sedona(Lo-Line)	06-08	31-40	Beru	1028	2000K	Yellow	52933-4D200
	Sedona(Hi-Line)	09-11	31-40	Beru	1068	2000K	Yellow	52933-2G200
	Sorento	07-09	31-40	TRW	1058	2000K	Yellow	52933-3E000
	Sorento	11		Continental	NEW	7000K		52933-2M000
	Soul	10-11		Continental	NEW	7000K		52933-2M000
	Spectra-5(Lo-Line)	07-09	31-40	TRW	1029**	2040K	Lt Blue	52933-2F000
	Sportage	06-08	31-40	TRW	1058	2000K	Yellow	52933-3E000
	Sportage(Lo-Line)	09-11	31-40	TRW	1029**	2040K	Lt Blue	52933-2F000
	Tuscany	07-08	31-40	TRW	1058	2000K	Yellow	Enhanced/Basic

**

Note: Use "TRW LoLine Fxd Dly" function on BarTec 400 or 400P to program the sensors.

DILL TPMS APPLICATIONS CHART ©

OE	Model	Model Year	Torque In-Lbs	OE Supplier	Dill Sensor #	Dill Kit #	Kit Color	OE Sensor Part #
Land Rover	LR2(315 Mhz)	08-10	71	Siemens	NEW	1050K	White	LR021936
	LR3(433 Mhz)	02-05	58	Beru	9003	1090K	Gray	Check VIN
	LR3(315 Mhz)	06-09	71	Siemens	1055	1050K	White	LR018860
	LR3(433 Mhz)	06-09	71	Siemens	1046	1050K	White	LR018861
	LR4(315 Mhz)	10-11	71	Siemens	NEW	1050K	White	LR021936
	Range Rover (315 Mhz)	06-09	71	Siemens	1055	1050K	White	LR018860
	Range Rover (315 Mhz)	10-11	71	Siemens	NEW	1050K	White	LR021936
	Range Rover (433 Mhz)	06-10	71	Siemens	1046	1050K	White	LR018861
	Range Rover Sport(315 Mhz)	06-09	71	Siemens	1055	1050K	White	LR018860
	Range Rover Sport(315 Mhz)	10-11	71	Siemens	NEW	1050K	White	LR021936
	Range Rover Sport(433 Mhz)	06-10	71	Siemens	1046	1050K	White	LR018861
Lexus	ES	07-10	35	Pacific	1204	1100K	Purple	42607-33021
	GS	05-10	35	Pacific	1204	1100K	Purple	42607-33021
	GX470	04-06	35	Pacific	1205	1110K	Teal	42607-35010
	GX	06-10	35	Pacific	1204	1100K	Purple	42607-33021
	HS Series	10				1100K	Purple	42607-75010
	IS Series	06-10	35	Pacific	1204	1100K	Purple	42607-33021
	LS	07-10	35	Pacific	1204	1100K	Purple	42607-33021
	LX	05-10	35	Pacific	1204	1100K	Purple	42607-33021
	RX	06-10	35	Pacific	1204	1100K	Purple	42607-33021
	SC430	02-07	27	Pacific	NA	1120K	Gold	42607-24040
	SC	07-10	35	Pacific	1204	1100K	Purple	42607-33021
Lincoln	Aviator(433 Mhz)	03-05	44	Schrader	9096	1060K	Rubine Red	4L2T1A150-BA
	MKS	11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	MKT	11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	MKX	11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	MKZ	10-11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Navigator	11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Navigator(433 Mhz)	03-04	44	Schrader	9096	1060K	Rubine Red	4L2T1A150-BA
	Navigator(315 Mhz)	05-06	44	Schrader	9135	1060K	Rubine Red	5L1Z1A150-AB
Mazda	2	11	71	Continental	NEW	7000K	NA	BBM2-37-140B
				Siemens-Fixed Angle	1056	NA	NA	FE01-37-140A/ GN3A-37-140B
	3	04	71	Fixed Angle	1056	1050K	White	GN3A-37-140B
	3	05	71	Siemens	1056	1050K	White	GN3A-37-140B
	3	06-10	71	Siemens	1056	1050K	White	GN3A-37-140B
	5	06-10	71	Siemens	1056	1050K	White	GN3A-37-140B
	6	05-10	71	Siemens	1056	1050K	White	GN3A-37-140B
	CX-7	07-10	71	Siemens	1056	1050K	White	GN3A-37-140B
	CX-9	07-10	71	Siemens	1056	1050K	White	GN3A-37-140B
	MX-5 Miata	06-10	71	Siemens	1056	1050K	White	GN3A-37-140B
				Siemens-Fixed Angle	1056	NA	NA	FE01-37-140A/ GN3A-37-140B
	RX-8	04	71	Siemens	1056	1050K	White	GN3A-37-140B
	RX-8	05-10	71	Siemens	1056	1050K	White	GN3A-37-140B
	Speed 3	10	71	Siemens	1056	1050K	White	GN3A-37-140B
	Speed 6	07-08	71	Siemens	1056	1050K	White	GN3A-37-140B
	Tribute	09-11	---	Schrader	9315	VS950	NA	ZZDA-37-140

DILL TPMS APPLICATIONS CHART ©

OE	Model	Model Year	Torque In-Lbs	OE Supplier	Dill Sensor #	Dill Kit #	Kit Color	OE Sensor Part #
M-Benz	C Class(433 Mhz)	07-10	53	Schrader	9214	2030K	Lt Grey	003 540 0217
	CL Class(315 Mhz)	00-06	35	Beru	9004	1090K	Gray	000 822 34 06
	CL Class(433 Mhz)	00-06	35	Beru	9001	1090K	Gray	000 822 3306
	CL Class(433 Mhz)	09-10	53	Schrader	9214	2030K	Lt Grey	003 540 0217
	CL 63-65-550-600 (315 Mhz)	07-10	53	Siemens	1054	1040K	Pantone Brown	002 540 7917
	CL 63-65-550-600 (433 Mhz)	07-10	53	Siemens	1049	1040K	Pantone Brown	002 540 8017
	CLKClass(315 Mhz)	06-07	35	Beru	9004	1090K	Gray	000 822 34 06
	CLK Class(433 Mhz)	08-09	53	Schrader	9214	2030K	Lt Grey	003 540 0217
	CLS 55-63-500-550 (315 Mhz)	06-09	53	Siemens	1054	1040K	Pantone Brown	002 540 7917
	CLS 55-63-500-550 (433 Mhz)	06-09	53	Siemens	1049	1040K	Pantone Brown	002 540 8017
	CLS Class(433 Mhz)	08-10	53	Schrader	9214	2030K	Lt Grey	003 540 0217
	E Class(315 Mhz)	00-05	35	Beru	9004	1090K	Gray	000 822 34 06
	E Class(433 Mhz)	00-05	35	Beru	9001	1090K	Gray	000 822 33 06
	E Class(315 Mhz)	06-10	53	Siemens	1054	1040K	Pantone Brown	002 540 7917
	E Class(433 Mhz)	06-10	53	Siemens	1049	1040K	Pantone Brown	002 540 8017
	E Class(433 Mhz)	10	53	Schrader	9214	2030K	Lt Grey	003 540 0217
	G Class(433 Mhz)	07-10	53	Schrader	9214	2030K	Lt Grey	003 540 0217
	GL Class(315 Mhz)	07-09	53	Siemens	1054	1040K	Pantone Brown	002 540 7917
	GL Class(433 Mhz)	07-09	53	Siemens	1049	1040K	Pantone Brown	002 540 8017
	GL(433 Mhz)	10	53	Schrader	9214	2030K	Lt Grey	003 540 0217
	GLK(433 Mhz)	10	53	Schrader	9214	2030K	Lt Grey	003 540 0217
	ML Class(315 Mhz)	06-10	53	Siemens	1054	1040K	Pantone Brown	002 540 7917
	ML Class(433 Mhz)	06-10	53	Siemens	1049	1040K	Pantone Brown	002 540 8017
	ML Class(433 Mhz)	10	53	Schrader	9214	2030K	Lt Grey	003 540 0217
	R Class(315 Mhz)	06-09	53	Siemens	1054	1040K	Pantone Brown	002 540 7917
	R Class(433 Mhz)	06-09	53	Siemens	1049	1040K	Pantone Brown	002 540 8017
	R Class(433 Mhz)	10	35	Schrader	9214	2030K	Lt Grey	003 540 0217
	S Class(315 Mhz)	00-06	35	Beru	9004	1090K	Gray	000 822 34 06
	S Class(433 Mhz)	00-06	35	Beru	9001	1090K	Gray	000 822 33 06
	S Class(315 Mhz)	07-10	53	Siemens	1054	1040K	Pantone Brown	002 540 7917
	S Class(433 Mhz)	07-09	53	Siemens	1049	1040K	Pantone Brown	002 540 8017
	S(433 Mhz)	10	53	Schrader	9214	2030K	Lt Grey	003 540 0217
	SL Class(315 Mhz)	00-05	35	Beru	9004	1090K	Gray	000 822 34 06
	SL Class(433 Mhz)	00-05	35	Beru	9001	1090K	Gray	000 822 33 06
	SL Class(315 Mhz)	06-09	53	Siemens	1054	1040K	Pantone Brown	002 540 7917
	SL Class(433 Mhz)	06-09	53	Siemens	1049	1040K	Pantone Brown	002 540 8017

DILL TPMS APPLICATIONS CHART ©

OE	Model	Model Year	Torque In-Lbs	OE Supplier	Dill Sensor #	Dill Kit #	Kit Color	OE Sensor Part #
M-Benz	SLK Class(433 Mhz)	08-10	53	Schrader	9214	2030K	Lt Grey	003 540 0217
	SLR Class(315 Mhz)	04-06	35	Beru	9004	1090K	Gray	000 822 34 06
	SLR Class(433 Mhz)	00-06	35	Beru	9001	1090K	Gray	000 822 33 06
	SLR Class(315 Mhz)	08-09	53	Siemens	1054	1040K	Pantone Brown	002 540 7917
	SLR Class(433 Mhz)	08-09	53	Siemens	1049	1040K	Pantone Brown	002 540 8017
Mercury	Mariner	09-11	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Milan	10	---	Schrader	9315	VS950	NA	9L3Z-1A189-A
	Monterey(315 Mhz)	04-05	44	Schrader	9135	1060K	Rubine Red	5L1Z1A150-AB
	Mountaineer(433 Mhz)	02-05	44	Schrader	9096	1060K	Rubine Red	4L2T1A150-BA
Mini	All(433 Mhz)	07-10	35	Beru	1027	1090K	Gray	36 23 6 781 847
	All(433 Mhz) (September 2009)	10	35	Beru	9012	1090K	Gray	36 10 6 790 054
Mitsubishi	Eclipse(Alloy)	06-10	45-53	Schrader	9034	1080K	Green	MN103081
	Eclipse(Steel)	06-07	45-53	Schrader	9069	1130K	Burgundy	4250A030
	Eclipse	11		Continental	NEW	7000K		4250B975
	Endeavor(433 Mhz)	04-06	45-53	Schrader	9028	1080K	Green	52088990AC
	Endeavor(Sept +)	06-10	45-53	Schrader	9034	1080K	Green	MN103081
	Galant(433 Mhz)	04-06	45-53	Schrader	9028	1080K	Green	MN103033
	Galant	07-10	45-53	Schrader	9034	1080K	Green	MN103081
	Galant(Steel)	07-09	45-53	Schrader	9069	1130K	Burgundy	4250A030
	Lancer	08-09	71	Siemens	1051	1050K	White	4250A225
	Lancer	10	71	Continental	NEW	7000K		4250B668
	Lancer	10	71	Continental	1051	1050K	White	Sensor Replacement Only
	Montero	03-05	45-53	Schrader	9034	1080K	Green	MN103081
	Outlander	07-09	71	Siemens	1051	1050K	White	4250A225
	Outlander	10	71	Siemens	1051	1050K	White	425B668
	Raider(HP)	08-09	53	Schrader	9154	2030K	Lt. Grey	56029319AB
Nissan	350Z	04-06	45-60	Schrader	9064	1080K	Green	40700-CD001
	350Z	07-09	50-70	Schrader	9204	2030K	Lt Grey	40700-1AA0C
	370Z(Base)	09-10	50-70	Schrader	9204	2030K	Lt Grey	40700-JK00C
	Altima	06-10	50-70	Schrader	9204	2030K	Lt Grey	40700-JA01B
	Armada(Alloy)--SE	05-08	49	Schrader	9161	1080K	Green	40700-CK001
	Armada(Steel)	05-06	49	Schrader	9069	1130K	Burgundy	40700-CK002
	Armada-LE	08-11	50-70	Schrader	9204	2030K	Lt Grey	40700-JA01B
	Cube	09-10	50-70	Schrader	9204	2030K	Lt Grey	40700-1AA0C
	Frontier	03-04	45-60	Schrader	9064	1080K	Green	40700-CD001
	Frontier(Alloy)	05-08	49	Schrader	9161	1080K	Green	40700-CK001
	Frontier(Steel)	05-07	49	Schrader	9069	1130K	Burgundy	40700-CK002
	Frontier(Steel)	08-10	50-70	Schrader	9204	2030K	Lt Grey	40700-JA01B
	GT-R	09-11	50-70	Schrader	9204	2030K	Lt Grey	40700-1AA0C
	Maxima(Alloy)	06-07	49	Schrader	9161	1080K	Green	40700-CK001
	Maxima(Post-April)	07-10	50-70	Schrader	9204	2030K	Lt Grey	40700-JA01B
	Murano	03-06	45-60	Schrader	9064	1080K	Green	40700-CD001
	Murano	07-10	50-70	Schrader	9204	2030K	Lt Grey	40700-JA01B
	Pathfinder	03-04	45-60	Schrader	9064	1080K	Green	40700-CD001
	Pathfinder(Steel)	04	49	Schrader	9069	1130K	Burgundy	40700-CK002
	Pathfinder	05-06	49	Schrader	9161	1080K	Green	40700-CK001
	Pathfinder	07-10	50-70	Schrader	9204	2030K	Lt Grey	40700-JA01B

DILL TPMS APPLICATIONS CHART ©

OE	Model	Model Year	Torque In-Lbs	OE Supplier	Dill Sensor #	Dill Kit #	Kit Color	OE Sensor Part #
Nissan	Quest(Steel)	04-07	49	Schrader	9069	1130K	Burgundy	40700-CK002
	Quest(Alloy)	05-06	78	Schrader	9161	1080K	Green	40700-CK001
	Quest	07-09	50-70	Schrader	9204	2030K	Lt Grey	40700-JA01B
	Rogue	08-10	50-70	Schrader	9204	2030K	Lt Grey	40700-1A00C
	Sentra(Alloy)	07-08	75	Schrader	9161	1080K	Green	40700-CK001
	Sentra(Steel)	07-10	50-70	Schrader	9204	2030K	Lt Grey	40700-JA01B
	Titan(Alloy)	05-07	49	Schrader	9161	1080K	Green	40700-CK001
	Titan(Steel)	04-05	49	Schrader	9069	1130K	Burgundy	40700-CK002
	Titan(Steel) (Post April)	07-11	50-70	Schrader	9204	2030K	Lt Grey	40700-JA01B
	Versa	07-11	50-70	Schrader	9204	2030K	Lt Grey	40700-JA01B
	Versa(Alloy)	07-08	71	Schrader	9161	1080K	Green	40700-CK001
	Xterra	03-04	45-60	Schrader	9064	1080K	Green	40700-CD001
	Xterra	05-06	49	Schrader	9161	1080K	Green	40700-CK001
	Xterra(Steel)	06-07	49	Schrader	9069	1130K	Burgundy	40700-CK002
	Xterra	07-10	50-70	Schrader	9204	2030K	Lt Grey	40700-JA01B
Pontiac	G3	09-10	---	Schrader	9153	VS950	NA	25920615
	G5	08	80	Siemens	1047	1050K	White	15921013
	G5	09-10	---	Schrader	9153	VS950	NA	25920615
	G6(Pre-10/15)	08	80	Siemens	1047	1050K	White	15921013
	G6(Post-10/15)	08-10	---	Schrader	9153	VS950	NA	25920615
	G8	08-09	---	Schrader	9153	VS950	NA	25920615
	Grand Prix	07-08	80	Siemens	1047	1050K	White	15921013
	Grand Prix	08	---	Schrader	9153	VS950	NA	25920615
	Montana	08	80	Schrader	1047 **	1050K or 1070K	White or Blue	15268606
	Solstice	08-10	80	Siemens	1047	1050K	White	15921013
	Torrent	07-09	80	Siemens	1047	1050K	White	10394110
	Vibe	08-10	35	Pacific	1204	1100K	Purple	88974915
	Wave	08-09	---	Schrader	9153	VS950	NA	25920615
	**The 1050K is to be used on the Siemens sensors and the 1070K is to be used on the Schrader sensors.							
Porsche	911(433 Mhz)	06-08	31-40	Beru	9001	1090K	Gray	99760602101
	911(433 Mhz)	09-10	31-40	Beru	9008	1090K	Gray	99760602120
	911(315 Mhz)	06-08	31-40	Beru	9004	1090K	Gray	
	Boxster(433 Mhz)	06-10	31-40	Beru	9001	1090K	Gray	99760602101
	Boxster(315 Mhz)	06-08	31-40	Beru	9004	1090K	Gray	
	Carrera GT(433 Mhz)	04-09	31-40	Beru	9001	1090K	Gray	99760602101
	Cayenne(433 Mhz)	02-06	31-40	Beru	9005	1090K	Gray	95536166101
	Cayenne(315 Mhz)	09-10	31-40	Beru	9004	1090K	Gray	95560602301
	Cayenne(433 Mhz)	07-10	31-40	Beru	9007	1090K	Gray	95560602100
	Cayman(433 Mhz)	06-10	31-40	Beru	9001	1090K	Gray	99760602101
	Panamera	10-11	31-40	Beru	9004	1090K	Gray	99760602321
	Panamera	10-11	31-40	Beru	9008	1090K	Gray	99760602120
Rolls Royce	Phantom(433 Mhz)	07-10	31-40	Beru	1027	1090K	Gray	NA
	Cabrio(433 Mhz)	07-10	31-40	Beru	1027	1090K	Gray	NA
Saab	9-3(433 Mhz)	04-07	62	Schrader	9078	2010K	Lt Brown	13172567
	9-3(433 Mhz)	08-10	62	Schrader		2010K	Lt Brown	13227143
	9-5(433 Mhz)	04-07	62	Schrader	9078	2010K	Lt Brown	13172567
	9-5(433 Mhz)	08-10	62	Schrader		2010K	Lt Brown	13227143
	9-7X(315 Mhz)	05-09	62	Schrader	9116	1070K	Blue	25774006

DILL TPMS APPLICATIONS CHART ©

OE	Model	Model Year	Torque In-Lbs	OE Supplier	Dill Sensor #	Dill Kit #	Kit Color	OE Sensor Part #
Saturn	Astra(433 Mhz)	08-09	62	Schrader	9078	2010K	Lt Brown	13172567
	Astra	10	---	Schrader	9153	VS950	NA	12768826
	Aura(<10/14/07)	07-08	80	Siemens	1047	1050K	White	15921013
	Aura(>10/14/07)	08-10	---	Schrader	9153	VS950	NA	25920615
	Lamda Crossover	07-08	80	Schrader	1047 **	1050K or 1070K	White or Blue	15268606
	Outlook	07-08	80	Siemens	1047	1050K	White	15921013
	Outlook	09-10	---	Schrader	9153	VS950	NA	25920615
	Sky	08-09	80	Siemens	1047	1050K	White	15921013
	Vue	07-10	---	Schrader	9153	VS950	NA	25920615
**The 1050K is to be used on the Siemens sensors and the 1070K is to be used on the Schrader sensors.								
Scion	TC	06-11	35	Pacific	1204	1100K	Purple	42607-33011
	XB	08-11	35	Pacific	1204	1100K	Purple	42607-33011
	XD	08-11	35	Pacific	1204	1100K	Purple	42607-33011
Smart	Fortwo(433 Mhz)	08	53	Siemens	1049	1040K	Pantone Brown	004 542 1518
	Fortwo(433 Mhz)	08-10	53	Schrader	9214	2030K	Lt Grey	002 540 0217
Subaru	B9 Tribeca	06-07	66	Schrader	9081	1080K	Green	28103AG00A
	Forester	08-10	---	Schrader	9203	VS950	NA	28103AG01C
	Impreza	08-10	---	Schrader	9203	VS950	NA	28103AG01C
	Legacy	04-07	66	Schrader	9081	1080K	Green	28103AG00A
	Legacy	08-11	---	Schrader	9203	VS950	NA	28103AG01C
	Outback	04-07	66	Schrader	9081	1080K	Green	28103AG00A
	Outback	08-11	---	Schrader	9203	VS950	NA	28103AG01C
	Tribeca	08-10	---	Schrader	9203	VS950	NA	28103AG01C
Suzuki	Equator	09-10	68	Schrader	9204	2030K	Lt Grey	43211-82Z00
	Forenza	07-08	---	Schrader	9153	VS950	NA	43130-85Z03
	Grand Vitara	07-10	80	Schrader	9087	2010K	Lt Brown	43130-54J21
	Kizashi	10	62	Continental	1051	1050K	White	43130-57L00
	Reno	07-08	---	Schrader	9153	VS950	NA	43130-85Z00
	SX4	07-10	80	Schrader	9087	2010K	Lt Brown	43130-54J21
	Verona	05-06	80	Schrader	9082	2010K	Lt Brown	43130-86Z20
	XL-7	05-06	80	Schrader	9087	2010K	Lt Brown	43130-54J21
	XL-7	07-10	62	Siemens	1047	1050K	White	43130-78J10
Tesla	Roadster	10	40-50					6004985
Toyota	4 Runner	03-05	35	Pacific	1205	1110K	Teal	42607-35010
	4 Runner	06-11	35	Pacific	1204	1100K	Purple	42607-33021
	Avalon	07-11	35	Pacific	1204	1100K	Purple	42607-06011/33011
	Camry	07-11	35	Pacific	1204	1100K	Purple	42607-06011/33011
	Corolla	07-10	35	Pacific	1204	1100K	Purple	42607-06011/33011/33021
	FJ Cruiser	08-10	35	Pacific	1204	1100K	Purple	42607-33011
	Highlander	07-11	35	Pacific	1204	1100K	Purple	42607-06011
	Land Cruiser	05-11	35	Pacific	1204	1100K	Purple	42607-33011
	Matrix	07-10	35	Pacific	1204	1100K	Purple	42607-06011/33011
	Prius	06-10	35	Pacific	1204	1100K	Purple	42607-06011
	RAV 4	06-11	35	Pacific	1204	1100K	Purple	42607-06011
	Sequoia(20 Degrees)	04-07	35	Pacific	1204	1110K	Teal	42607-0C020
	Sequoia(40 Degrees)	04-07	35	Pacific	1203	1110K	Teal	42607-0C010
	Sequoia(20 Degrees)	08-11	35	TRW	1206	1110K	Teal	42607-0C050/08010
	Sequoia(40 Degrees)	08	35	TRW	1206	1110K	Teal	42607-0C060

DILL TPMS APPLICATIONS CHART ©

OE	Model	Model Year	Torque In-Lbs	OE Supplier	Dill Sensor #	Dill Kit #	Kit Color	OE Sensor Part #
Toyota	Sienna(20 Degrees)	06-11	35	TRW	1206	1110K	Teal	42607-0C050/42607-08010
	Solara	06-08	35	Pacific	1204	1100K	Purple	42607-06011
	Tacoma(20 Degrees)	05-06	35	Pacific	1204	1110K	Teal	42607-0C020/AD020
	Tacoma(40 Degrees)	05-09	35	Pacific	1203	1110K	Teal	42607-0C010/AD010/04010
	Tacoma(20 Degrees)	07-11	35	Pacific	1204	1100K	Purple	42607-06011
	Tundra(20 Degrees)	05-06	35	Pacific	1204	1110K	Teal	42607-0C020
	Tundra(40 Degrees)	05-06	35	Pacific	1203	1110K	Teal	42607-0C010
	Tundra(20 Degrees)	06-11	35	TRW	1206	1110K	Teal	42607-0C050/08010
	Tundra(40 Degrees)	06-11	35	TRW	1206	1110K	Teal	42607-0C060
	Venza	09-10	35	Pacific	1204	1100K	Purple	42607-06011
Volkswagen	Yaris	07-10	35	Pacific	1204	1100K	Purple	42607-33011
	Beetle	08-10	71	Siemens	1053	1030K	Orange	1K0907253D
	CC	09-11	71	Siemens	1053	1030K	Orange	1K0907253D
	EOS	07-11	71	Siemens	1053	1030K	Orange	1K0907253D
	GLI	08-09	71	Siemens	1053	1030K	Orange	1K0907253D
	Golf	10-11	71	Siemens	1053	1030K	Orange	1K0907253D
	GTI(Standard Hex)	06-11	71	Siemens	1053	1030K	Orange	1K0907253D
	GTI(O-ring Hex)	06-07	71	Siemens	1041	1031K	Lt Green	1K0907253E
	Jetta(Standard Hex)	06-10	71	Siemens	1053	1030K	Orange	1K0907253D
	Passat(Standard Hex)	06-10	71	Siemens	1053	1030K	Orange	1K0907253D
	Passat(O-ring Hex)	06-08	71	Siemens	1041	1031K	Lt Green	1K0907253E
	Phaeton(433 Mhz) (thru May 2007)	02-07	35	Beru	9001	1090K	Gray	4D0 907 275C
	Phaeton(433 Mhz) (June 2007)	07	35	Beru	9007	1090K	Gray	4F0 907 275B
	Phaeton(315 Mhz)	03-07	35	Beru	9004	1090K	Gray	4D0 907 275A
	R32	08-10	71	Siemens	1053	1030K	Orange	1K0907253D
	Rabbit(Standard Hex)	06-10	71	Siemens	1053	1030K	Orange	1K0907253D
	Rabbit(O-ring Hex)	06-07	71	Siemens	1041	1031K	Lt Green	1K0907253E
	Routan(433 Mhz)	09-10	71	Siemens	1043	1050K	White	7B0907253
	Tiguan	09-11	71	Siemens	1053	1030K	Orange	1K0907253D
	Touareg(433 Mhz)	02-06	35	Beru	9005	1090K	Gray	7L0 907 275B
	Touareg 2(433 Mhz)	07-10	35	Beru	9007	1090K	Gray	4F0 907 275B
Volvo	C30(433 Mhz)	07-11	71	Siemens	1044	1050K	White	31302096
	C70(433 Mhz)	07-11	71	Siemens	1044	1050K	White	31302096
	S40(433 Mhz)	07-11	71	Siemens	1044	1050K	White	31302096
	S60(315 Mhz)	04-10	44	Schrader	9156	2010K	Lt Brown	31200923
	S60(433 Mhz)	11	71	Siemens	1044	1050K	White	31302096
	S80(315 Mhz)	04-07	44	Schrader	9156	2010K	Lt Brown	307489910
	S80(433 Mhz)	07-11	71	Siemens	1044	1050K	White	31302096
	V50(433 Mhz)	08-11	71	Siemens	1044	1050K	White	31302096
	V70(315 Mhz)	04-07	44	Schrader	9156	2010K	Lt Brown	307489910
	V70(433 Mhz)	08-10	71	Siemens	1044	1050K	White	31302096
	XC60	09-10	44	Schrader	9156	2010K	Lt Brown	31200923
	XC60	11		NEW				31201481
	XC70(315 Mhz)	04-07	44	Schrader	9156	2010K	Lt Brown	307489910
	XC70(433 Mhz)	08-11	71	Siemens	1044	1050K	White	31302096
	XC90(315 Mhz)	05-11	44	Schrader	9156	2010K	Lt Brown	31200923

DISCLAIMER: The data presented in this document is accurate to the best of our knowledge and is regularly updated with the latest data available in the marketplace. We encourage you to check back for the latest edition of this data, however, we cannot guarantee accuracy of the information provided. Also, please note that several vehicle applications require knowledge of the VIN number as the sensor design could have changed mid-model year.