



TIRE PRESSURE WARNING ECU

COMPONENTS




TIRE PRESSURE WARNING
ANTENNA AND RECEIVER

6.8 (69, 60 in.*lbf)



TIRE PRESSURE
WARNING ECU

TIRE PRESSURE
WARNING VALVE
AND TRANSMITTER



NUT


4.0 (41, 35 in.*lbf)

GROMMET


WASHER

VALVE
CORE

CAP



N*m (kgf*cm, ft.*lbf) : Specified torque



TW