



F RELAY LOCATIONS


[Engine Compartment]



[Body]




[Instrument Panel]



F RELAY LOCATIONS


② : Engine Room R/B	Engine Compartment Left (See Page 20)
---------------------	---------------------------------------




F RELAY LOCATIONS

○ : Driver Side J/B

Lower Finish Panel (See Page 21)




[Driver Side J/B Inner Circuit]



F RELAY LOCATIONS

○ : Center J/B

Near the Steering Column Tube (See Page 21)



[Center J/B Inner Circuit]