

Transfer Shift Lever Knob

ATF Level Gauge

Front Console Upper Panel

Transmission Shift
Lever Assembly

Front Console Box

12 (120, 9)

5.9 (60, 52 in.-lbf)

Oil Filler Pipe

12 (120, 9)

34 (350, 25)

Transfer Shift
Lever

Snap Ring

5.0 (51, 44 in.-lbf)

13 (130, 9)

◆ O-ring

39 (400, 29)

Oil Cooler Pipe

Starter

Plug for Hydraulic Test

71 (730, 53)

Torque Converter
Clutch

x 6

Engine Rear
Mounting

65 (660, 48)

Rear End Plate

41 (420, 30)

x 6

48 (490, 35)

No. 4 Crossmember

◆ Gasket

62 (630, 46)

◆ Gasket

72 (730, 53)

72 (730, 53)

Support Bracket

Front Exhaust Pipe

18 (185, 13)

18 (185, 13)

No. 3 Crossmember

44 (450, 33)

California:

◆ Gasket

48 (490, 35)

Front Propeller Shaft

74 (750, 54)

25 (260, 19)

74 (750, 54)

62 (630, 46)

◆ Gasket