





REMOVAL HOLE COVER






Disengage the 4 claws and remove the hole cover.

ELECTRICAL WIRING DIAGRAM NAVIGATION SYSTEM



16 P



14 P

