

OK

3	Inspect sensor installation and tooth of RH camshaft timing pulley.
---	---

NG	Tighten sensor. Replace RH camshaft timing pulley
----	---

OK

Check and replace ECM (See page IN-28).
--