

EXTERIOR PANELS / TRIM: AUTOMATIC RUNNING BOARD: REMOVAL; 2014 MY 4Runner [08/2013 -]

Friday, March 1, 2019 3:58 PM

Last Modified: 2-6-2019	6.8:8.0.48	Doc ID:
Model Year Start: 2014	Model: 4Runner	Prod Date Range: [08/2013 -]
Title: EXTERIOR PANELS / TRIM: AUTOMATIC RUNNING BOARD: REMOVAL; 2014 MY 4Runner [08/2013 -]		

REMOVAL

HINT:


- Use the same procedure for the RH and LH sides.
- The procedure listed below is for the LH side.

1. REMOVE ROCKER PANEL MOULDING (w/ Intuitive Parking Assist System)

INFO


2. REMOVE STEP PLATE

- (a) Using a 5 mm hexagon wrench, remove the 4 hexagon bolts and step plate.




3. REMOVE POWER LIFT STEP ASSEMBLY

- (a) Disconnect the connector.



- (b) Remove the 4 bolts, 2 nuts and power lift step assembly.



Inserted from <<https://techinfo.toyota.com/t3Portal/document/rm/RM23V0U/xhtml/RM00000477B009X.html?sisuffix=ff&locale=en&siid=1551481118078>>