




- N 4 Front Seat Outer Belt Assembly RH
- N 5 Front Door Courtesy Light Switch Assembly RH
- N 6 Rear Floor Side Airbag Sensor
- N 7 Rear Door Courtesy Light Switch Assembly RH
- N 8 Diode (Rear Door Courtesy Switch RH)
- N 9 Rear Airbag Sensor RH
- N 10 Curtain Shield Airbag Assembly RH
- N 11 Stereo Component Amplifier Assembly
- N 12 Stereo Component Amplifier Assembly
- N 13 Stereo Component Amplifier Assembly
- N 14 Stereo Component Amplifier Assembly
- N 15 No. 1 with Box Speaker Assembly
- N 16 Rear Power Point Socket Assembly
- N 17 Rear Power Point Socket Assembly
- N 18 Power Outlet Socket
- N 19 Voltage Inverter Assembly
- N 20 Voltage Inverter Assembly
- N 21 Outside Luggage Electrical Key Antenna
- N 22 Junction Connector

Position of Parts in Body

