


9/1/08

*4-Power
VRBAN
P.EXTRE*

2008/4/8

System Settings



SDARS and Aux use the same audio input.

- SAT tuner, turns on and off via AVC-LAN
- While you are listening to SAT, if you have an AUX device plugged in and playing you will hear the AUX play over the SAT.

FUJITSU TEN

Slide: 23

Stand-By Function Access

- Press PWR button for one second; "GOOD-BYE will be displayed. This ensures that unit is in Stand-by mode. Press and hold combination of buttons to enable certain functions



- Press and hold for 3 seconds. This function ENABLES/DISABLES AUX MODE



- Press and hold for 3 seconds. This function chooses LEFT / RIGHT side speaker



- Press and hold for 3 seconds. This function LOCKS/UNLOCKS CD EJECT Function

FUJITSU TEN

Slide: 24